

BB complete

colour matched worktop sealant

worktop joints
guaranteed for
three years



one job | one cartridge | 3 year guarantee!

With BB Complete all worktop joints are guaranteed for 3 years* against moisture ingress and expansion. Get the benefit of total peace of mind on Bushboard worktop installations.

- 290ml cartridges available in 18 colour ways
- Advanced formulation for superb results
- Easy and flexible to work with for bonding, sealing and finishing
- Colour matches to suit over 100 designs
- Cartridges suit a mastic gun
- 290ml - approximately 20 linear metres at a 5mm bead or 9 joints

For full details contact our Customer Support Team on 01933 232 272 or email us at help@bushboard.co.uk

* This 3 year guarantee applies only to Bushboard Omega, Odyssey and Options worksurfaces when installed in residential environments and which have been subject to fair wear and tear. BB Complete must be used in accordance with our recommended installation instructions. A proof of purchase for adhesive and worksurfaces will be required in the event of a query.

Jet Black

Slate Grey

Basalt Grey

Pewter Grey

Silver Grey

Ash Grey

Ice White

Ivory

Vanilla

Oatmeal

Fudge

Mushroom

Toffee

Chestnut

Chocolate

Olive Green

Cherry Red

Aqua

jointing | sealing | bonding | finishing

user guide



Jointing

Preparation

Ensure all surfaces are cut accurately, clean, dry and completely free of dust. Well cut joints which fit tightly will ensure an inconspicuous finish.

Biscuits will ensure strong level joints. Always use connector bolts to assure strength. Cut bolt slots using a jig and hand router. They should be no deeper than 25mm from the rear face. 20mm deep on 30mm worksurfaces and 18mm deep on 22mm worksurfaces providing you are using Bushboard slimline bolts.

Assembly

BB Complete has a joint open time of 10-15 minutes allowing more time to make adjustments.

Apply a continuous 5mm diameter bead around the border of one cut edge, 5mm in from the bottom and top faces following the profile and completing a loop. Do not reduce the amount of adhesive recommended.

Insert the connector bolts and tighten to the nip point, ensuring that BB Complete squeezes out around the entire joint including the bottom face. Check the joint is level, adjusting as necessary using a rubber mallet. Fully tighten the bolts a maximum of two full turns past the nip point.

Using a soft plastic or laminate scraper, remove excess adhesive avoiding smears. Take care not to scratch the surface particularly with gloss finish worktops.

Moisten a clean, lint-free cloth with white spirit and carefully remove the residue, wiping at 90° across the joint to avoid removing adhesive before the joint cures.

Do not wipe down with water or any other solvents and allow 24 hours for the joint to fully cure before using.

Sealing

For all areas where raw chipboard has been exposed, such as sink cut-outs, spread a bead of BB Complete using a spatula ensuring total coverage.

To seal a worktop to a wall apply a generous bead of BB Complete along the back edge of the worksurface ensuring there are no gaps. Smooth the bead using a spatula or use a rubber gloved finger dipped in white spirit.



Bonding

Upstands and splashbacks

Ensure that all surfaces are fully dry, dust free and stable before bonding.

Apply three beads of BB Complete along the length of the **upstand** and dot and dab BB Complete to the back of the **splashbacks**, a generous seating bead along the bottom raw edges sufficient to ensure it is totally sealed against moisture ingress.

Clean away any excess with a clean wipe moistened with white spirit. Do not use water or other solvents.

Allow to cure for 24 hours before use.

Finishing

Consider masking the area to be finished with a good quality masking tape to produce a neat straight edge.

Hold the nozzle at a 45° angle and apply an even bead along the area to be finished. Shaping of the bead is possible using a specialist smoothing tool, or simply using a rubber gloved finger dipped in white spirit. Do not use water or other solvents.

Once satisfied with the final finish any masking tape should be peeled away immediately.

Clean away any spillage with a clean wipe moistened with white spirit. Do not use water or other solvents.

Allow to cure for 24 hours before use.

Aftercare

BB Complete is designed to produce strong waterproof joints. However, it is advised that the home owner takes care with heat radiating appliances or excess moisture. Do not site kettles, toasters, deep fat fryers or other heat generating small appliances over joints. Wipe up and dry all spills immediately. Taking good care of your worksurfaces will ensure they give many years' service.